

OPERATING INSTRUCTIONS:

ON/OFF:

Press ON/OFF to toggle on and off. Device will automatically shut off after 20 minutes if not used.

ZERO:

Vent pressure port to atmosphere. Press ZERO button until the LCD displays "---" then release it.

UNITS:

To change units, press both ON/OFF and ZERO buttons simultaneously.

BATTERY:

Remove retaining screws on end cap at base of instrument to replace battery when LOW BAT is displayed.
Use 9volt alkaline battery.



DWYER INSTRUMENTS, INC.
MICHIGAN CITY, IN 46360
e-mail: info@dwyer-inst.com
<http://www.dwyer-inst.com>