

## **OPERATING INSTRUCTIONS:**

### **ON/OFF:**

Press ON/OFF to toggle on and off. Device will automatically shut off after 20 minutes if not used.

### **ZERO:**

Vent both pressure ports to atmosphere. Press ZERO button until the LCD displays "----" then release it.

### **UNITS:**

To change units, press both ON/OFF and ZERO buttons simultaneously.

### **HOLD READING:**

Press HOLD to hold current reading. Press again to resume measurement.

### **MIN/MAX :**

First button press displays MIN value. Second press displays MAX value. Third press returns to normal measurement. Reset MIN and MAX by pressing ON/OFF button when MIN or MAX is displayed.

### **BATTERY:**

Remove retaining screws on end cap at base of instrument to replace battery when LOW BAT is displayed.  
Use 9volt alkaline battery.



**DWYER INSTRUMENTS, INC.**  
**MICHIGAN CITY, IN 46360**  
e-mail: [info@dwyer-inst.com](mailto:info@dwyer-inst.com)  
<http://www.dwyer-inst.com>